

# Ambiente PS Daily Cleaning Instructions

**CAUTION: DO NOT PLACE YOUR HANDS OR FINGERS INSIDE MACHINE!**

1. Press "Cleaning Program" button once.



2. Remove grounds bin within 3 seconds and empty grounds into a trash can.



3. Use long cleaning brush to wipe coffee grounds from bottom of inside area into drip tray. Do not touch brew group or any other parts of inside area!



4. After brushing grounds from bottom, slide grounds bin back into place.



5. Wait until display shows message "cleaning program insert tablet".



6. Lift small lid located between the two bean hoppers and drop in one Schaefer cleaning tablet.



7. Press "Cleaning Program" button again to start flush cycle (it runs about 5 minutes). All beverage selection buttons will be locked during this time.



8. When the cleaning cycle has completed, display will read "select beverage".

9. Assuming you're closing, turn off machine. The next morning, when turning the machine back on, a brief flush cycle will be activated (about 2 minutes) and the machine will dispense a short espresso shot.

10. If you're not closing your store (24 hr. operation): turn off the machine and turn it back on. This will activate a brief flush cycle (about 2 minutes) and a short espresso shot will be dispensed.